

EZ truss Freestanding counter Setup Instructions



1. Open section with top frame attached by folding panel frame out from body frame
2. Repeat with opposite side.



3. Fold bottom down and lock into opposing tabs.
4. Fold top out and lock in place.



5. Go to the side of the counter with velcro on the top and bottom edges. This is the side that will have the solid panel. Velcro the solid panel into place with the additional velcro showing on the sides.



6. Velcro the flaps to the solid panel vecro edges. Be careful to make the seams as invisible as possible.



7. Repeat procedure on the front, this time velcroing the panels to the frame. Be careful not to get any material beyond the seam edge. It will interfere with the door.



8. Install the doors with the longer pin up. Locate the holes in the frame and insert the longer pin into hole in the underside of the top frame and then drop in into the hole in the bottom frame.



Repeat with locking door and then velcro on the top. If you are positioning the counter between 2 uprights whether as a backwall counter or in the open, we have included 2 small tubes with velcro, you may use these by inserting between the truss tubes and velcroing them to the counter side. This will prevent the counter from moving separate from the truss.