
Show 'n Rise (CURVED) 4QUAD_TABLE TOP

Item #	NAME	Graphic Panels	Viewable Graphic Size (when flat)	Fabric Panels
339000	HARDWARE KIT-no lights	NONE	NONE	NONE
339001	6FT FABRIC KIT-w/light	NONE	No graphics-FABRIC	(2)Center (2) End
339002	6FT MURAL KIT/Fabric Ends-w/light	(2) Center	55.25″w x 59.5″h	(2) End
339003	6FT MURAL KIT-w/light	(2)Center (2) End	101.25″w x 59.5″h	NONE






Display Set-Up

Step 1

Remove all parts from your Hard Case (3) and place on a flat, clean surface. Review the Frame (4) and notice where the pivoting light clips are located. This will determine the TOP of the display.



Step 3


Push all locking clips together to secure the Frame (4) in its expanded position.





Step 2


Pull the Frame (4) up and out from the corners until it is fully expanded on the table.





Step 4:

With 2-sectioned Mag Rail (2) folded, start with BOTTOM section and slide back slot onto Mural **Graphic Face Plates** (1) on Frame.




bottom face plate

Display Set-Up Continued...

Step 5:

Unfold Mag Rail (2) and secure TOP section onto BOTTOM section. When done you will have Mag Rails (2) on all front connection points as well as on the back vertical ends.





lock middle section to bottom section


Step 6

Determine which Mag Rail (2) light will attach to, and insert clip (7-b) from LED kit (7) into top of Mag Rail (2). Install LED light (7-c) from LED kit (7) onto inserted clip (7-b)



Step 8

Install the Panels (6) to the Frame. Start with the end. Remove it from protective sleeve and while holding it in a curved position hook the notches located on top of the panel (6) to the pins at the top of front end and back end Mag Rail (2). With top notches both hooked slide your hands down the panel securing it to the vertical Magnets.



Step 10

Plug light (7) into power source. Display is now ready.






,BACK END BACK END

Step 7

Set all plastic wrapped panels (6) out on floor in order of how they will be installed. All panels are installed by hooking the notch located on the top of the panel (6) to the pins at the top of the mag rail.



(KEEP the protective sleeves as they will be used for storage.)

Step 9

Secure the rest of the panels using the same method as in Step 8.



Disassembly Instructions

Step 1

Remove all Panels (6) and carefully roll them up graphic/ fabric side out. Place into clear protective sleeves.



Step 3

Unplug and remove light (7c) and clip (7b) from Frame (1). Place in carrying case.



Step 5

Collapse Frame. MAKE SURE ALL LOCKING CLIPS **ARE IN OPEN POSITION** before collapsing Frame (4)





SET-UP NOTE:

Display should have Face Plates (1) already installed in Frame (4). If not, Slide (with force)

the Face Plate (1) into the hubs. Typically you will slide RIGHT to LEFT when looking at the face of the Frame (4).

See opposite for Face Plate Locations.

Step 2

Place rolled Panels (6) into Hard Case (3).



Step 4


Remove all Mag Rails (2) from Frame (4). Collapse and place in hardware bag (5)



Step 6

Place all parts in the open center area inside the shipping case with rolled Panels (6).







(all hubs)



BACK VIEW (vertical ends only)

NOTE: FRAME HARDWARE HAS HUBS THAT CAN BE INTERCHANGED TO DISPLAY OTHER PRODUCTS

Conversion kits sold separately-contact client services for more details

Warranty Information: All products are designed to provide the user with a cost-effective and durable product. Standard warranty is a 'one year parts and labor' warranty which warrants product against defects in material and workmanship. It does not cover damage due to accidents, abuse, or normal wear and tear. Products found to be defective will be replaced or repaired at factory's discretion.