



Graphic Installation

Pop Up Display




WARNING! DO NOT FORCE CLOSED.
To avoid damage, all hooks must be disconnected before collapsing frame.




1

Assemble frame and lay flat on its back.
Remove existing graphic.



2

Starting at one corner, attach velcro on graphic to velcro on frame.
Overlap velcro of graphic a 1/4" on all sides of velcro of frame.
Note: Velcro should not be flush.



3

Work in continuous direction around the frame
until graphic is completely attached.




4

If needed, adjust velcro for taut fit.

Setup Instructions

Pop Up Display




WARNING! DO NOT FORCE CLOSED.
To avoid damage, all hooks must be disconnected before collapsing frame.



Remove frame and graphic from bag.




Ensure "adjustable knobs" of frame are on the floor. Pull up display into upright position.



Lock all hooks between front and back hubs.



Adjust leveling knobs for desired angle. OneFabric™ display can now be moved easily into position.



OPTIONAL
Attach lights to top of frame by sliding the plastic X Blocks under the frames cross sections.